




CABINET PARTS

For Models: LER6620PQ0, LER6620PT0
(Designer White) (Biscuit)

29" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: LER6620PQ0, LER6620PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT8535829	Literature Parts Installation Instructions	15	3394083	Clip, Front Panel (2)	36	3393549	Door, Front White
	LIT8522243	Use & Care Guide	16	3392100	Foot, Dryer		3977241	Biscuit
	LIT8533770	Sheet, Cycle Feature		279810	Foot – Optional (Extended Length Package Of 2) (Not Included)	37	690270	White Handle, Door
	LIT8528187	Wiring Diagram					3977242	Biscuit
Following May Be Purchased			17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	38	3406129	Seal & Bearing Assembly
DO-IT-YOURSELF REPAIR MANUALS			18		Cabinet (Includes Illus. 4)	39	279393	Terminal Block Kit (For Terminal Block)
	LIT677818	Dryer		8530603	White	40	3393008	Screw, 10–16 x 1/2
2	343641	Screw, 10–16 x 1/2		8530606	Biscuit	41	3397659	Block, Terminal
3	693995	Screw, Hex Washer Head	19	98234	Clip, Ground	51	238088	Hinge, Top (2)
4	8541400	Bracket, Cabinet	20	690363	Lock, Front Top (2)	53	691366	Idler & Pulley Assembly
5	3396795	Cover, Block	21	695620	White	56	8066065	Belt, Drive
6	342043	Screw, 10–32 x 3/8		3977244	Biscuit	57	348780	Base, Motor
7	3396805	Panel, Rear	23	685203	Clip, Felt Pad (3)	58	3400500	Bolt, 5/16–18 x 3/4
8	8546676	Clip, Door Spring	24	3389441	Catch, Door Assembly	59	3394341	Pulley, 60 Hz.
10	3406107	Door Switch Assembly	26	337189	Clip, Hinge (2)	62	8538262	Motor Assembly 60 Hz.
11	697773	Screw, 6–20 x 7/8	27	694091	Screw, 8–18 x 3/8	63	660658	Clamp, Motor
13	3357011	Screw, 10–16 x 1/2	28	8066056	Hinge, R.H.	64	3404162	Clamp, Motor (W/Shield)
14	8541401	Spring, Door (2)		8066057	Hinge, L.H.	67	3390731	Seal, Door
			33	696144	Strike, Door	68	697776	Screw, 10–32 x 5/8 (External Ground)
			35	695737	Door, Rear			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LER6620PQ0, LER6620PT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LER6620PQ0, LER6620PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	10		Screen, Lint	29	3390646	Screw, 8-18 x 5/16
3	694419	Buzzer		8557857	White	30	357213	Nut, Push-In (2)
4		Cap, End (L.H.)		8557858	Biscuit	31	8299867	Harness, Wiring
	8271365	White	13	688983	Screw, 8-18 x 5/8	39	3404233	Switch,
	8271368	Biscuit	14	3400859	Screw, Grounding			Push-To-Start
5	8539888	Jumper, Wire (PTS to Buzzer)	15	8536939	Clip, Spring	48		Timer Knob
6	388326	Screw, Console	16		Top			Assembly
7	693995	Screw, Hex Head		8557930	White		8544955	White
8		Cap, End (R.H.)		8557931	Biscuit		8544956	Biscuit
	8271359	White	18	94614	Terminal	50	3936144	Connector
	8271362	Biscuit	21	8299778	Timer, 60 Hz.	53	8271418	Bracket, Control
9	3395683	Housing, Connector (Motor)	23	3394427	Clip, Harness	54		Panel, Control
			26		Knob, Control		8545966	White
				8544935	White		8546011	Biscuit
				8544936	Biscuit			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

279948	Kit, Dryer Repair
3404351	Dry Rack
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray


PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LER6620PQ0, LER6620PT0
(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)

Illus. No.	Part No.	DESCRIPTION
11	8557384	Housing, Blower
12	8066155	Clip, Heater Box
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
17	3403585	Element, Heater
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
22	3394196	Seal, Blower
24	8066086	Drum Hole Plug

Illus. No.	Part No.	DESCRIPTION
25	3390647	Screw, 8-18 x 1/2
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403491	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST